## Ford\_V01.10 Daig Function List(Note:For reference only)

## NOTES:

- This function is supported.
- $\bigcirc$  This function is not supported.
- lacktriangle This function is the new feature in this version.

Mode1	EcuInfo.	Read Codes	Erase Codes	LiveData
(All MYO5) Escape/Tribute/Maverick/Mariner	0	•	e	•
626 / 626 Wagon / Telstar	0	•	•	•
AEROSTAR	0	•	•	•
Aspire	0	•	•	•
Aviator	0	•	•	•
В-Мах	0	•	•	•
B-Series / Bravo / Fighter / Courier / Ranger / Everest / Endeavour	0	•	•	•
Bantam	0	•	•	•
Blackwood	0	•	•	•
Blue Bird C-Class Vision	0	•	•	•
Bongo / Bongo Brawny / Spectron	0	•	•	•
Bongo Brawny / Econovan / MAZDA E-Series	0	•	•	•
Bronco	0	•	•	•
BT-50 / Ranger	0	•	•	•
C-MAX	0	•	•	•
CAPELLA / CAPELLA W / Telstar / Telstar W	0	•	•	•
Cargo	0	•	•	•
CF/LCF	0	•	•	•
Continental	0	•	•	•
Contour	0	•	•	•
Cougar	0	•	•	•
Crown Victoria	0	•	•	•
DEMIO / Festiva Mini Wagon	0	•	•	•
E-Series	0	•	•	•
E-Series Shuttle Bus	0	•	•	•
Econovan	0	•	•	•
EcoSport	0	•	•	•
Edge	0	•	•	•
Escape / Mariner Hybrid	0	•	•	•
Escape / Tribute (2006/4 -)	0	•	•	•
Escape / Tribute (2006/3)	0	•	•	•
Escape / Tribute / Mariner	0	•	•	•
Escape / Tribute / Maverick	0	•	•	•
Escape/Kuga	0	•	•	•
Escort	0	•	•	•
Everest / Endeavour	0	•	•	•
Excursion	0	•	•	•
Expedition	0	•	•	•
Explorer	0	•	•	•
Explorer Sport	0	•	•	•
Explorer SportTrac	0	•	•	•

n .=0				
F-150	0	•	•	•
F-150 SuperCrew (4 full size doors)	0	•	•	•
F-250	0	•	•	•
F-250 Light Duty	0	•	•	•
F-Series	0	•	•	•
F-Series Super Duty	0	•	•	•
F350/450	0	•	•	•
Fairlane / LTD	0	•	•	•
Fairmont	0	•	•	•
Familia / Laser	0	•	•	•
Festiva	0	•	•	•
Festiva Sedan	0	•	•	•
Fiesta	0	•	•	•
Fiesta / Ikon	0	•	•	•
Fiesta / Mazda 121 / Bantam	0	•	•	•
Fiesta 3-Door	0	•	•	•
FIGO	0	•	•	•
Five Hundred	0	•	•	•
Five Hundred (MYO5) / Montego (MYO5)	0	•	•	•
Flex	0	•	•	•
Focus	0	•	•	•
Focus C-MAX	0	•	•	•
FORD GT	0	•	•	•
Freestar / Monterey	0	•	•	•
Freestyle	0	•	•	•
Friendee / Freda / Bongo Friendee	0	•	•	•
Fusion	0	•	•	*
Galaxy	0	•	•	•
Galaxy / S-Max	0	•	•	•
Granada / Scorpio	0	•	•	•
Grand Marquis	0	•	•	•
Ikon	0	•	•	
KA	0	•	•	•
Kuga	0	•	•	•
Laser / 323 / Tierra	0	•	•	
Liata	0	•	•	
LS	0	•	•	
Marauder	0	•	•	
Mariner	0	•	•	
	0	•		
Mark LT	0	•	•	•
Mark VIII Milan	0	•	•	
				_
Millenia / Eunos 800	0	•	•	•
MKS	0	•	•	•
MKT	0	•	•	•
MKX	0	•	•	•
MKZ	0	•	•	*
Mondeo 	0	•	•	•
Montego	0	•	•	•
Motorhome / Stripped Chassis / Step Van	0	•	•	•
Mountaineer	0	•	•	
Mustang	0	•	•	

w	1 0 1			
Mystique	0	•	•	•
Navigator	0	•	•	•
Navigator L	0	•	•	•
Novo KA	0	•	•	•
Premacy / Ixion	0	•	•	•
Probe / MX-6	0	•	•	•
Puma	0	•	•	•
Ranger	0	•	•	•
Ranger / Courier / Mazda B Series /Bravo	0	•	•	•
Ranger / Mazda B-Series / Courier	0	•	•	•
Roadster / MX-5	0	•	•	•
S.A. Courier	0	•	•	•
S.A. Fiesta	0	•	•	•
Sable	0	•	•	•
Scrum (2005 / 9) DG64V / DG64W	0	•	•	•
Street Ka	0	•	•	•
Taurus	0	•	•	•
Taurus X	0	•	•	•
Telstar	0	•	•	•
Thunderbird	0	•	•	•
Titan	0	•	•	•
Titan (Isuzu OEM)	0	•	•	•
Town Car	0	•	•	•
Tracer	0	•	•	•
Transit	0	•	•	•
Transit Connect	0	•	•	•
Transit Connect / Tourneo Connect	0	•	•	•
V362	0	•	•	•
Villager	0	•	•	•
VX-1	0	•	•	•
Windstar	0	•	•	•
Zephyr/MKZ	0	•	•	•
ł				

## Ford\_V01.10 OIL Function List (Note:For reference only)

## NOTES:

- ullet This function is supported.
- \* This function may be supported, which depends on the actual condition of the vehicle.
- O This function is not supported.
- ▲ This function is the new feature in this version.

▲ This function is the new feature in this version	
Vehicle	0IL
Aviator	•
Crown Victoria	
E 150 Series	•
E 250 Series	
E 350 Series	
E 450 Series	•
E-Series	•
EcoSport	•
Edge	•
Escape	•
Escape Hybrid	•
Expedition	•
Explorer	•
Explorer Sport Trac	•
F-150	•
F-Series	•
F250SD Series	•
F350SD Series	•
F450 Series	•
F550 Series	•
Fiesta	•
Five Hundred	•
Flex	•
Focus	•
Focus 1.6 Tdci 09	•
Freestar	•
Freestyle	•
Fusion	•
Fusion Hybrid	•
Galaxy	•
Grand Marquis	•
17	•
Kuga Ls	•
Mariner	•
	•
Mariner Hybrid Milan	•
MITAN MKS	•
MKT	-
	•
MKZ	
MKZ Hybrid	•
Mondeo	•
Montego	•
Monterey	•
Mountaineer	•
Mustang	•
Navigator	•

Navigator L	•
New Mondeo	•
S-MAX	•
Sable	•
Taurus	•
Taurus X	•
Town Car	•
Transit	•
Windstar	•